



DELMHORST
EUROPE

WHEN ACCURACY IS THE POINT.™

JL-2000

moisture meter leather



The moisture content of hides is a crucial factor during all stages of leather processing. A moisture meter can be an invaluable tool for monitoring the moisture content of leather to ensure a high-grade end product. The JL-2000 leather moisture meter is the perfect quality control tool for tanneries everywhere.

Don't leave the quality of your product to chance. Check moisture content with the JL-2000 leather moisture meter.



Your Benefits:

- Bright, clear digital display
- Averages up to 100 readings
- Moisture Range: 10%-28% on leather
- Built-in calibration check
- Integral contact pins mounted on top of meter provide 8mm (5/16") penetration
- Built-in connector accepts any Delmhorst electrode
- Size: 20x80x4cm (8x3x1 5/8")
- Weight: 285gr. (10 oz.)
- Rugged construction ensures years of reliable use
- Sturdy plastic carrying case
- 9V battery
- 1-year warranty

Electrode and MCS:



4-E leather

Pin type, comes with 4 uninsulated 2497/A-100 contact pins for 8mm (5/16") penetration

Benefits

Use for tough leather



MCS-JL-2000

This moisture content standard is great for verifying that your JL-2000 leather moisture meter is in calibration. With two electrical resistance values (13% and 21%) to test your meter against, you can be sure that your readings will stand up to the strictest standards of accuracy. The MCS-JL-2000 is also available with a letter of certification traceable to NIST.